


ShenZhen GreenTouch Technology Co.,Ltd

F-series Assemble User Manual



Contact: Peter.Wan

Tel:+86-755-29371519-8018

Mobile: 13823548639

Fax:+86-755-29235565-8008

Email:peter@greentouch.com.cn

Skype:wanli889

QQ:2355562940

Wechat:13823548639


Web: www.greentouch.com.cn

Add:3rd Floor,Building A2,ShenZhen Low-Carbon Science Industrial Park,Sillicon Valley Power,Guiyue Road,Zhangge Market,Guanlan Town,LongHua New District,ShenZhen City,518110,China

Accessory list (as below pic):


- 1. X axis transmitting tub: 1 PCS
- 2. Y axis transmitting tub: 1 PCS
- 3. Y axis receiving tube: 1 PCS
- 4. X axis receiving tube: 1 PCS

Screws (KM2.5x4mm) : 14Pcs ((2pcs backup)



Step1 :



Match the NO. on the touch frame (No. A match No.A, No.B match No.B, No.C match No.C ,No.D match No.D)





Step2:

Open the cover of each corner (as below)



Step3:

Connect the spare part via the 10pin connector and fix the cover of corner



Step 4 :

According to the same principle, repeat the corner B,C,D and finish the assembling as below



Attention:

1. Must open the cover of the corner before connecting the frame (as below) , in case the 10 pin connector broke.